



Installing Flat or Post style Pedestal Stands



ANCHORING

1. Position the Pedestal where you intend to install your ASHTRASH unit.
2. With a ½" masonry bit drill and a rotary hammer drill, drill one anchor hole at a time. Place a drop in anchor into that hole. Using a center punch set the anchor, then thread and tighten a bolt into the anchor. Then drill the next hole and follow the same procedure for each hole.



MOUNTING

1. Remove the nuts and washers from the stud on the mounting plate.
2. Each ASHTRASH unit comes with predrilled holes for mounting.
3. Open the ASHTRASH unit and lift it, positioning onto the studs at the height you wish to use.



Flat Pedestal Stands are intended for use where mounting to the wall is not permitted or desired. The Flat Pedestal Stand permits mounting ½" away from the wall. Due to the risk of flexing the Flat Pedestal is not recommended for use in front of glass windows.

Post Pedestal Stands are intended for use in locations that are out in the open or in front of glass windows. Their very rigid construction resist flexing.

The ASHTRASH units will fit either style of Pedestal stand.